

# VERNIER THROTTLE SYSTEM for Caterpillar Engines

## Class1

607 NW 27 Ave. Ocala, FL 34475

Ph: (352) 629-5020 Fax: (352) 629-2902



## **Overview**

### **Throttle Interface Control Module**

### **System Overview**

The *Class1* Vernier Throttle Interface is designed to allow industry standard vernier style controls (such as the Felsted Electronic Vernier II Control) and other potentiometer controls to be used with electronically controlled engines. This unit will work with electronically controlled Caterpillar Engines (C10, C12, 3116, 3126, 3176, 3406, 3116B and 3126B) using a Pulse Width Modulated (PWM) Signal.

The interface converts a linear voltage input (potentiometer) into a PWM signal to control the engine. True variable speed control is attained and the unit will maintain a selected engine RPM irrespective of the engine load within it's horsepower and torque capabilities. The interface can be used to govern engine speed for various applications including PTO driven generators and pumps and has an internal idle validation circuit that can be overriddenusing an input that allows for a fast idle activation.

**Included in the package** The throttle control is available alone or as a package shipped with the following components.

interface module vernier control user manual

### Operation

**Variable Throttle Control** When the interface has power provided by the interlock circuit, variable engine control is available to the operator using the vernier control. If the vernier control is open more than 10% when power is applied to the interface, the interface will maintain the engine at idle RPM until the throttle is closed and then re-opened. This feature prevents sudden unexpected increases in engine speed when the unit is initially activated.

**High Idle Control** An input (C4) is available to bring the engine speed to a pre-determined engine RPM (High Idle) from a remotely mounted switch or load management device. When the interface is powered up with this input active, the idle validation routine is bypassed and the interface will increase the engine speed to the preset RPM. This speed can be set by an external potentiometer or resistor network.

### Installation

**Control Module** The interface module requires minimal space (3.63" x 4.75" x1.00"). The module is watertight and may be mounted in any location that is not subject to extreme temperature or vibration.

**Wiring** The interface package comes with cables and leads to make the following connections:

Power and Ground

Engine Control Extension Cable High Idle connector with leads

Refer to the diagrams in the manual for specific wiring requirements.

Refer to the engine manufacturer's Electronic Application & Installation Guides for detailed information on engine electrical interfacing.

## Interlocks



Class1 provides a variety of engine controls that are used in a broad range of applications, therefore it is impossible for Class1 to determine the suitability of a particular control for any specific application. The flexibility of our products allows them to be used in a limitless number of custom applications. Class1 can advise you of the features that are available on a given product so that you can determine what product will meet your needs. We believe that the Original Equipment Manufacturer's (OEM) engineering departments should be qualified experts in their product field and are the authorities on product application and safety. Since our products are typically used in safety critical applications, the OEM must undertake appropriate testing to prevent injury to the end user.

## **WARNING**




IT IS THE PURCHASER'S RESPONSIBILITY TO DETERMINE THE SUITABILITY OF ANY PRODUCT FOR AN INTENDED APPLICATION, AND TO INSURE THAT IT IS INSTALLED AND GUARDED IN ACCORDANCE WITH ALL APPLICABLE FEDERAL, STATE, LOCAL AND NFPA SAFETY AND HEALTH REGULATIONS, CODES AND STANDARDS.

**NOTE:** The interlock schemes shown in this manual are examples only and may not be suitable for specific applications. The throttle interface is active whenever power is applied.

**Special Programming** The ECM must be programmed for remote throttle operation and there are several considerations including vehicle speed and max RPM that need to be configured.



# **Connectors**



## **Connector Information**


Position A B	Connector 12015792 Wire Color Red Black	Terminal 12089188 <u>Description</u> Throttle Inter  Ground	Seal 12015899 lock
C2 Position A B C	Connector 12015793  Wire Color  White  Blue  Orange	Terminal 12089188 <u>Description</u> Throttle grou  Throttle Sign  Throttle Sour	al
C3 Position A	Connector 12010973 Wire Color Yellow	Terminal 12089040 <u>Description</u> PWM Signal	Seal 12015899
C4 Position A	Connector 12015791 Wire Color Green	Terminal 12089188 <u>Description</u> Fast Idle*	Seal 12015899

<sup>\*</sup> This input bypasses idle validation and allows the interface to command engine speed as soon as power is applied.

DOC 101058C\_c:\manuals\throttles\cat\catthrot.p65

# manuals\throttles\cat\_3176.ai..021497


# Caterpillar C10, C12, 3176 & 3406 ECM






# HI-Idle

## Wiring the Class1 Vernier Throttle with high idle option only



manuals\throttles\cat\cathigh.ai..110298

## Wiring the Class1 Vernier Throttle with a remote high idle option



SIGNAL C2-B CONNECT TO VERNIER THROTTLE INPUT AT RELAY 1 CONNECT TO HIGH IDLE POT INPUT AT RELAY 1


GROUND C2-A HOOKED IN PARALLEL TO HIGH IDLE POT. FROM C2-A

RELAY 3 DISABLES HIGH IDLE WHEN OK TO PUMP/PTO ENGAGED SIGNAL IS PRESENT

RELAY 2 SELECTS THE SOURCE OF THE INTERLOCK (HIGH IDLE OR PTO)

RELAY ONE SELECTS WHICH THROTTLE SIGNAL (HIGH IDLE OR VERNIER) IS DELIVERED TO THE INTERFACE MODULE

## Caterpillar 3126 ECM




Wiring the Class1 Vernier Throttle Interface with a fast idle option

Manuals\Throttles\catvthi.ai..120996

# manuals\throttle\cat\cat3126b.ai..100198

# Caterpillar 3126B HEUI ECM Throttle Interface Module



or	~ • • • • • • • • • • • • • • • • • • •
Vehaicle Harness Connector ECM Side	
Veha	-0000000000000000000000000000000000000
	2 2 2 4 P 5000000000000000000000000000000000000


Parameter	Available	Defaults
PTO PTO Top Engine Limit PTO RPM set speed PTO Cab Throttle RPM PTO activates cooling fan Torque Limit	Remote Throttle 600-2120 Idle-PTO TEL TEL, Idle, PTO TEL Normal, Continuous 200 lb-ft to Rated	Off 2120 0 RPM TEL Normal
Idle PTO vehicle speed limit	1 to 15 MPH	1 MPH

Programming Considerations


CAT J1/P1 Connector ECM RIGHT SIDE



# **B HEUI**



DOC 101058C\_c:\manuals\throttles\cat\catthrot.p65



DOC 101057C\_c:\manuals\throttles\cats\catthrot.p65



# **Operation**

When the throttle interface module is powered up by the safety (interlock) system the throttle module will perform a self check and the module will then output a PWM signal of 12 %.

The interface will verify that the throttle is fully closed. If the throttle is not fully closed, the interface module will not increase the PWM until the zero position is detected.

**IMPORTANT** The throttle interface module will not command increased speed from the engine until the zero position is detected. This feature is present to avoid unintentional increases in engine speed should the throttle be left in the open position.

The fast idle input overrides this feature and should be used with caution.

When finished operating the remote throttle, the operator should return the throttle to idle and turn the control to it's full clockwise position. This will insure a zero throttle position.

NOTE: The new 3126B and 3116B HEUI engines perform their own idle validation for remote throttle operations. This presents a timing and signal problem that must be overcome to use the interface module for Fast Idle.

For questions or concerns regarding the interface module, call *Class1* at 352-629-5020 FAX 352-629-2902